

Call list

1. View call history list on webpage.

Phonebook

1. Add speed dial contacts on webpage.

Speed dial

1. Configure speed dial on webpage (Number keys 0-9).
2. Long press the corresponding number key to achieve speed dial.

Redial

1. Press , redial a call number.

Do not disturb

1. Enable the device do not disturb mode on webpage.

Fanvil

V2.2

Packaging list



IP Phone



Handset



Quick Installation Guide



Handset Cord

Keys features



Hold key, Hold/Resume the call



Hands-free key
Activate/deactivate hands free



Mute key, with red color LED
In idle mode: ringer off
In communication mode:
mute/un-mute a call



Volume +/- key
In idle mode or during ringing:
increase or decrease ringer volume
In communication: increase or decrease earpiece, headset or hands-free volume



Status indicator
with two-color LED



Redial key, Access to redial the last record




DSS Key, It can be set as function key/speed dial key, etc.

H2U Quick Installation Guide


Installation the device

- **Wall mounting (without screws and screw anchors)**

- 1) Drill two holes in the wall, the vertical distance between the two holes is 136.2 or 161.2mm;
- 2) Drive in 2 screw anchors and screws in turn;
Note : 5mm is reserved between the screw cap and the wall for easy installation of the phone base.
- 3) Connect the Ethernet cord, handset cord and power;
- 4) Align the wall mounting holes on the base with the screws made in step 2, slide down to complete the installation.



- **Connecting to the Device**
Please connect power adapter, network and handset to the corresponding ports as described in below picture.
- ① Power port: connect the power adapter;
 - ② Network port: connecting local area network or internet;
 - ③ Handset port: connect IP Phone handset.



Configuration

Configuration via Web

1. Get the IP : Long press  key, the IP Phone will report the IP address by itself.
2. Login: Input the IP address in the web browser. The PC and phone should be in the same IP address segment(The default username and password are both 'admin' .)
3. Configure: Select network/Account, etc. and fill the relevant content.
4. Save the configuration.

Making a call

1. **Direct dialing**: lift the handset and enter the phone number, press  key .
2. **Hands-free**: enter phone number press  key and press  or vice versa.

Accepting a call

1. **With the handset**: pick up the handset.
2. **With the hands-free**: press  .

Putting a call on hold/resume

1. Press  key, caller is put on hold.
2. Press again to  key , resume the call.

Call Mute

1. Press  to Mute the microphone during the call.
2. Press  again to un-mute the conversation.

Fanvil Technology Co., Ltd

Website: www.fanvil.com
EEmail: sales@fanvil.com support@fanvil.com
Tel: +86-755-2640-2199 Fax: +86-755-2640-2618
Add: 4F, Block A, Building 1#, GaoXinQi Hi-Tech Park (Phase-II), 67th District, Bao'An, Shenzhen, China

Fanvil Technology Co., Ltd
www.fanvil.com

P/N:CJBA100111D0